

SEGMENT BARS

DESCRIPTION	PART NUMBER
Comes with: Roller, roller bolt, lock washer, hex jam nut, and hex head machine bolt	
4x4 Segment Bar	
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-30°	ES00526A
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-45°	ES00526B
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-60°	ES00526C
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-75°	ES00526D
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-90°	ES00526E
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-135°	ES00526F
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-180°	ES00526G
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-30°	ES00528A
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-45°	ES00528B
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-60°	ES00528C
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-75°	ES00528D
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-90°	ES00528E
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-135°	ES00528F
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-180°	ES00528G
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-30°	ES00530A
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-45°	ES00530B
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-60°	ES00530C
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-75°	ES00530D
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-90°	ES00530E
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-135°	ES00530F
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-180°	ES00530G
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-30°	ES00531A
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-45°	ES00531B
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-60°	ES00531C
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-75°	ES00531D
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-90°	ES00531E
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-135°	ES00531F
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-180°	ES00531G
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-30°	ES00532A
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-45°	ES00532B
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-60°	ES00532C
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-75°	ES00532D
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-90°	ES00532E
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-135°	ES00532F
OHM-44-IPO-44-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-180°	ES00532G
6x6 Segment Bar	
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-30°	ES00537A
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-45°	ES00537B
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-60°	ES00537C
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-75°	ES00537D
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-90°	ES00537E

OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-135°	ES00537F
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-2'-0" R-180°	ES00537G
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-30°	ES00539A
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-45°	ES00539B
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-60°	ES00539C
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-75°	ES00539D
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-90°	ES00539E
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-135°	ES00539F
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-3'-0" R-180°	ES00539G
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-30°	ES00541A
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-45°	ES00541B
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-60°	ES00541C
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-75°	ES00541D
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-90°	ES00541E
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-135°	ES00541F
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-4'-0" R-180°	ES00541G
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-30°	ES00542A
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-45°	ES00542B
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-60°	ES00542C
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-75°	ES00542D
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-90°	ES00542E
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-135°	ES00542F
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-5'-0" R-180°	ES00542G
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-30°	ES00543A
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-45°	ES00543B
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-60°	ES00543C
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-75°	ES00543D
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-90°	ES00543E
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-135°	ES00543F
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-6'-0" R-180°	ES00543G
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-8'-0" R-30°	ES00544A
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-8'-0" R-45°	ES00544B
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-8'-0" R-60°	ES00544C
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-8'-0" R-75°	ES00544D
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-8'-0" R-90°	ES00544F
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-8'-0" R-135°	ES00544G
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-8'-0" R-180°	ES00544H
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-12'-0" R-15°	ES00547A
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-12'-0" R-30°	ES00547B
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-12'-0" R-45°	ES00547C
OHM-66-IPO-46-RT-SEGMENT BAR SUB-ASSEMBLY-12'-0" R-60°	ES00547D